



The Tags

Attach a tag to everything you wish to protect




If a Tag is taken too close to the Chirp-Edge Hub then an alarm will sound in the Tag until it is deactivated using the Remote.

There are currently three types of Tag - **Lanyard**, **Surface** and **Wrap**.

Lanyard Tag

Our most popular tag, this features a 17cm loop which can be detached and fastened around the product you wish to protect - perfect for handbags or items of clothing.

The Lanyard Tag is sold in packs of 25 and we offer varying lengths of cables as optional accessories ranging from 12cm to 200cm.



Surface Tag

The Surface tag has a small depression switch which means the tag can then be attached to the surface of product by either adhesive pad, or zip tie.

If the tag is removed from the product then the depression switch is activated even if the tag is not within range of the Chirp-Edge Hub.

There are a range of accessories available to make the Surface Tag even more effective and with a larger number of applications.



Security without barriers



Wrap Tag

The Wrap Tag consists of two plastic discs that separate and then tightly attach either side of a product. It's perfect for boxed products such as electronic gadgets. The Wrap Tag will alarm if taken too close to the Chirp-Edge hub.



Tag Accessories

For the Lanyard style tag we sell different length cables, ranging from Extra Short to Extra Large. This enables you to loop the tag around larger - or even multiple - products.




- 12cm - Extra Short
- 17cm - Short
- 25cm - Medium
- 100cm - Large
- 200cm - Extra Large

For the Surface style tag we sell a range of accessories to help better secure Tags to your items and we are continually innovating to make Chirp-Edge compatible with even more products.



Tag Cage
Secure to any product



Adhesive Pads
Help secure to any product

Security without barriers